



www.mud-busters.com

Email us for digital instructions: Mudbusters@gracemfg.com

Thank you for purchasing MudBuster's **fender flares for the Arctic Cat Wildcat 1000!** We manufacture the best-selling fender flare kits for UTVs and side by sides! All MudBusters products are made in the USA, and these fender flares are manufactured from high-quality American made material. Your new extended fenders are designed to deflect debris and reduce the amount of mud that typically gets thrown from the tires into unwanted areas. They can withstand a lot of abuse, but they are not designed for crash protection, absorbing impacts, rollovers, or uprooting trees. If you have an accident or if you happen to damage your fenders, order discounted replacement fenders by phone (for existing customers only). Unlike other manufacturers, you do not have to buy a complete set if you damage just one fender.

IMPORTANT:

Some of the images in the instructions below may differ from the actual product. In our continual effort to increase customer satisfaction, we may change the style, material, and/or hardware to serve you better. If your fenders get slightly distorted while in transit, apply pressure to the distorted areas to straighten them out before installation.

Use caution when drilling into the factory panels of your vehicle. Make sure that you do not penetrate the surrounding parts or the chassis (unless instructed). Self-tapping screws and push rivets are included as an effective and easy way to fasten the fender flares to your machine. However, you can use other methods of securing our extended fenders to your vehicle as well (i.e., rivets, misc. hardware, etc.). Remember, it may be helpful to have a friend assist you with the installation.

Unboxing:

Carefully open your package from the box's top (or bottom) by removing the staples with a flat-head screwdriver or pliers. Slide the fenders out of the box and make sure that any staples do not scratch your fenders. MudBusters are formed to fit your machine but shipped in a narrow box. You may find it necessary to apply pressure and re-bend some of your fenders for a better fit. Don't worry, they're very durable and will not break from re-shaping them!

Note: Using a larger drill bit may allow the fender to come off when riding! The rivets need to be a tight fit to secure the fender flare to the fender. We recommend a 21/64" drill bit.

Note: Max coverage set shown. Smaller sets (Mud-Lite, or Race-Lite) may have less hardware in the front of the front fender or the lower front of the rear fender than pictured. In these cases, it may be helpful to use the rear mounting locations first for installation ease.

Thank you for your business!

Please send us pictures and/or videos of your vehicle with MudBusters installed to our Facebook page

<https://www.facebook.com/UTVMudbusters/>

#utvmudbusters.com

or email us via mudbusters@gracemfg.com

We may feature your ride on our website, social media, Amazon and/or eBay!

For technical assistance or product inquiries, please call us at:

1-844-MUD-FLAPS or 844-683-3527

Hours: Mon-Fri 8-4 MST

▲ WARNING

This product can expose you to chemicals, including phthalates which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more info, go to www.p65Warnings.ca.gov

Installation Instructions

Arctic Cat Wildcat 1000



Front Fender Flare Installation



- 1) Remove the factory hardware in **Figure 2** and Insert the passenger side splash guard as shown in **Figure 1**. (Note: the driver's side splash guard has a hole in it to clear the brake master cylinder wires.)
- 2) After you have removed the factory hardware in **Figure 2**, replace the bolts with (2) M6x30mm bolts and (2) washers provided in the hardware kit.



- 3) Remove the 2 factory bolts located right behind the tires on the outer floorboard area.
- 4) Place the fender against the outer floorboard, match up hole #1 as in shown in **Figure 3**, insert the factory hardware, and continue on to hole #2.
- 5) Using a drill bit, drill out through the 3rd hole shown in **Figure 4** and install (1) 3/4" bolt with a washer on each side and a lock-nut to secure it.





Installation Instructions

Arctic Cat Wildcat 1000

Front Fender Flare Installation



- 6) The upper corner of each front fender requires a bracket to install it properly. Have a friend push the fender flare against the factory fender so you can mark the hole from underneath the fender (**Figure 5**). (You may need to loosen the lower bolts to do so). Drill a hole and install (1) 3/4" bolt, a washer, and a locknut.
- 7) Place the bent tab on the fender flare behind the factory flare and mark the hole to be drilled. Install (1) 3/4" bolt, a washer, and a locknut. (**See Figure 6**)
Note: the bracket may have to be bent to achieve a tight fit.



Installation Instructions

Arctic Cat Wildcat 1000

Rear Fender Flare Installation



- 1) Remove the bolts shown in **Figure 7** and remove the rear factory fenders.
- 2) Place the rear factory fenders on a table and remove the rubber bushings in the factory fenders



Figure 7

- 3) Insert bolts with a washer on each side and a lock-nut on the underside of the fender. (see **Figure 8**)




Figure 8

If you experience any gaps in the rear fenders after installation, add an L-bracket to the inside of the fender with the appropriate hardware in this location.

Installation Instructions

Arctic Cat Wildcat 1000

Rear Fender Flare Installation

- 4) Proceed to the bottom of the rear fender. Add (1) 1-1/4" bolt with a washer and a lock-not through the fender and the fender flare.
- 5) Re-install the rear fender.



- 6) Loosen the nut behind the tail light to create a gap to slide the below clamp through.
- 7) Slip the provided roll bar clamp through the gap and line up the hole in the fender with the holes in the clamp. Insert (1) 3/4" bolt with a washer and a lock nut.



Hardware Included

Front Fender Flares

- (2) Front fender extensions
- (8) 3/4"bolts
- (8) Lock-nuts
- (16) Washers
- (2) L-Brackets

Splash Guards

- (2) Splash Guards
- (4) M6 x 30mm bolts
- (4) Washers

Rear Fender Flares

- (2) Rear Fender Extensions
- (2) 1-3/4" Roll bar Clamps
- (8) 3/4" bolts
- (8) 1" bolts
- (2) 1-1/4" bolts
- (30) Washers
- (18) Lock-nuts
- (2) L-Brackets