



FALCON RIDGE


2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of Kubota RTV400-SDK01 KU-RTV400-SDK01

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

- Be sure to read these instructions thoroughly before unrolling and installing the Cab Enclosure. The installation is best done when the temperature is 65degrees F. or warmer. This is to help the adhesive Velcro strips adhere to the ROPS. If installation must be done in colder weather it will help to warm the Velcro Strips prior to installation.
- Carefully unroll the Cab Enclosure on a large clean flat surface that is free of dirt or other material that may soil or scratch the windows of the Cab.
- Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	22 each	3” long
“ “	2 each	11” long
“ “	2 each	15” long
Snap Studs	15 each (1 extra)	
Cab Enclosure	1 each	
- Begin by hanging the Door from the Velcro Tab across the top. Line the door up and mark where the adhesive Velcro needs to be to match up with the tab on the top of the door and place the adhesive Velcro on the frame.



- You will see a 36” Velcro tab sewn to the front of the doors. This tab is made to be able to cut it so that it will fit around the clamps holding the windshield on. Hold it up and mark where the clamps will hit the tab and cut roughly 2” out of the tab to allow it to fit around the clamp. Make sure to melt the edges

of the webbing with a lighter to prevent fraying. Next take the 36” adhesive Velcro strips and cut it to match up with the tabs leftover after cutting it. Remove one side of the clamps on the windshield and place the adhesive Velcro strips on the roll bars where they need to be, they should be facing the inside of the cab and attach the Velcro tabs to them. Next replace the clamps under the cab and repeat the directions for the other side of the windshield.

- You will also see a 3” Velcro tab sewn to the top front part of the door. Place the 3” adhesive Velcro strip in the bracket that holds the front cross bar and attach tab here. See photo
- Note the location for the 10” adhesive strip down the backside of the doors and install it here. Be sure the rear window is centered and you do not over pull one side over the other as this will cause the doors to fit improperly. Next wrap the roll cage with the 6” adhesive strips where there in a double-sided Velcro strip sewn to the cab. Then wrap the double-sided strip around the bar to secure.
- Mark the desired locations for the stud snaps on the front fenders. You will use 7 per side. The front of the door at the bottom is made so that the doors is pulled inside and snapped to the inside of the fender. Then install the stud snaps to the Mule using only a #2 Phillips screwdriver. **Caution: Do not use a drill as damage to the gas tank can occur!**
- To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2” in diameter to assure that the door will not stick out very far while stowed.

Cleaning and Storage Recommendations:

- Before removing the Falcon Ridge Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag (I recommend a Flannel or Micro Fiber Cloth) or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
- It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.

Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.

If ordered from Falcon Ridge please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Falcon Ridge without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Falcon Ridges many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

Warranty

To The Owner of this Product:

Thank you for purchasing one of Falcon Ridge Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.

Thank you,

Falcon Ridge