



## **FALCON RIDGE**

2515 Bypass Rd. Flemingsburg, KY 41041  
606-845-7439

**Instructions for Installation and Care of**  
**2019 Polaris Turbo S Poly Rear Window**  
PO-TURBO-S-RW02

**Notice:** Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.  
**NOTICE:** Please check contents of package for any damage and make sure all parts fit correctly and you are happy with the product before removing protective film. Once the film is removed you cannot return the product for a full refund.

1. Be sure to read these instructions thoroughly before opening and installing the Ranger RZR Turbo S Hard Rear Window.
2. Check over the parts included in the carton with the parts list shown below:  
Velcro Strap Clamps                      4 each
3. Begin by Pulling the Rear Window out and removing the protective film from both sides. Then take the window and install it in the roll cage from the inside. The window should look like the picture below.



4. Now you are ready to attach the Rear Window to the frame. Take the four strap clamps and put the rectangle through the matching hole in the rear window from the inside and

wrap the strap around the bar. Then put the strap under the metal bar and pull it tight back around the bar and secure the Velcro in place. Do this for all four locations on the rear window.

5. This concludes your installation. Enjoy!!