



TRAILARMOR.COM
839 HWY 2 CORINTH, MS 38834
(662) 233-5700

Installation Instructions

Installation Instructions for Yamaha Wolverine RMAX4 iMPact Front and Rear A-Arm Boot Guards TA011ARMIMP-YW-RMAX4

Warnings and Product Liability Disclaimer

This product is intended to be used as a cosmetic accessory under normal equipment operation and should not be depended upon or used as a safety device. Manufacturer assumes no liability for personal injury or equipment damage as the result of use or installation of this accessory. User assumes all risk. User should carefully read all instructions prior to installation.



Remove wheels and tires prior to beginning for easier install. Always secure vehicle with safety stands.

For Front Guards

- A. Locate the passenger front guard (engraved YW-RMAX-RF) from the a-arm set. Also, locate two supplied M6-1.0 x 50 mm. flat head socket cap screws. Holding the guard into position, insert one 50 mm. screw into each of the inside holes closest to the frame. Loosely tighten. See Picture 1.





TRAILARMOR.COM
839 HWY 2 CORINTH, MS 38834
(662) 233-5700

Installation Instructions

- B. Locate one supplied M6-1.0 x 25 mm. flat head socket cap screw. Insert the 25 mm. cap screw into the outside hole closest to the hub. See Picture 2. Alternate tightening all fasteners. Repeat for the opposite side.

For Rear Guards

- A. Locate the passenger side rear guard (engraved YW-RMAX4-RR). Also, locate four supplied M6-1.0 x 35 mm. flat head socket cap screws. Holding a-arm guard in place, insert one 35 mm. cap screw into each of the four holes of the rear guard. Loosely tighten until all screws are started. See Picture 3. Tighten all fasteners securely. Repeat for the opposite side.

