



Global West Suspension
655 SOUTH LINCOLN AVE / SAN BERNARDINO CA. 92408
PHONE 877-470-2975 / FAX 909-890-0703
Web address: www.globalwest.net

Part #PHC-2 Panhard Rod with Poly Ends
1982-02 Camaro/Firebird
Installation Instructions



1. Lift the rear of the vehicle and support with jack stands under the rear axle.
2. Remove the factory panhard rod from the vehicle. This rod extends across the back of the rear end. One end attaches to the unibody and the other end attaches to the rear end housing located at the left rear shock.
3. Install the new panhard rod with the grease fittings down, this will allow easy access.
4. Tighten the panhard rod bolt to axle 92 ft/lbs. Tighten the panhard rod to unibody brace 58 ft/lbs. Lower the vehicle to the ground.