

---

## What features are available with Connected Car on Alarm.com?

The following features are available with Connected Car on Alarm.com.

### Self-Installation

Alarm.com's Connected Car has a step-by-step guide on the Add Device Portal that walks the user through how to install the Car Connector.

For more information about installation, see [Car Connector \(ADC-3035L\) - Installation Guide](#).

Customer app installation:

Media, iframe, embed and object tags are not supported inside of a PDF.

### Geo-Services

Connected Car allows users to automate smart home settings based on the location of their vehicle. This can save them time and money by enabling Geo-Services to automatically adjust and send alerts for home automation devices.

When the Car Connector is added to the account, it is automatically added as a Geo-Device.

**Note:** Connected Car uses GPS accuracy, which allows for smaller Geo-Fences.

For more information about Geo-Services, see [Configure Geo-Services](#).

Media, iframe, embed and object tags are not supported inside of a PDF.

### Home automation and alerts

The following home automation and alerts can be created when Geo-Services is configured:

- Trigger lights when the car's Geo-Device leaves or enters a Geo-Fence.
  - For more information, see [What types of rules and schedules can be created for Z-Wave lights?](#)



- Trigger thermostats when the car's Geo-Device leaves or enters a Geo-Fence.
  - For more information, see [Configure the Smart Away thermostat schedule](#).
- Pause video rules while the car's Geo-Device is within a Geo-Fence.
  - For more information, see [Create/edit a video recording rule](#).
- Send alerts if the car's Geo-Device leaves a Geo-Fence without closing the garage door, locking the front door, or arming the system.
  - For more information, see [Create/configure a notification](#).

## Vehicle monitoring notifications

Connected Car allows users to monitor their vehicle’s location, diagnostics, and behavior. When users configure notifications, they can receive alerts about vehicle maintenance, unexpected movement, and more! Connected Car provides constant awareness and helpful insights, even when the car is parked with the engine off.

When adding a new notification, there is a new section for *Cars*. For more information about creating notifications, see [Create/configure a Connected Car notification](#).

Add a New Notification

Standard

Property Awareness

Family

Cars

Second Home

Reminders

Car Unexpected Movement Alarm

Get notified when the car is moved while the engine is off.

Car Event Alert

Get notified of important concerns, such as diagnostic issues, low car battery, and malfunction alerts.

Driver Behavior Alerts

Get notified about excessive speed, sudden acceleration or hard braking.

Car Started Alert

Receive a notification when the car's engine is turned on.





Media, iframe, embed and object tags are not supported inside of a PDF.

Thresholds for these alerts can be configured by going to the *Car Settings* page using the Customer Website or app. For more information about configuring settings, see [Configure Connected Car Settings](#).




## View real-time data

Maintenance alerts and real-time data in the mobile app help keep vehicles in good working order. For additional information, see [Connected Car Overview](#).


-  Check Engine
-  Low Battery
-  Low Fuel
-  Car Location and Trips

The following images display the Cars section on the app:

**Car Status**



**Car Trips**



**Car trip selection**

