

Voyager 8200 UC

Bluetooth stereo headset


User Guide

Contents

```
Headset overview 3
  Be safe 3
USB Bluetooth adapter 4
Connect and pair
  Connect to PC 5
  Configure USB adapter 5
  Pair to mobile device 5
  Pair mode 6
  Pair USB adapter again 6
  NFC pairing 7
Fit 8
Load software 9
  Update your Poly device 9
The Basics 10
  Power on/off
              10
  Volume 10
  Make/Take/End Calls 10
  Interact with Microsoft softphone
  Play/pause music 11
  Track selection 11
  Voice control 11
  Charge 11
More Features 13
  Use sensors 13
  ANC 13
  OpenMic 13
Troubleshooting 14
Support 16
```



Headset overview



(1)	Volume dial	
Siri, Google Assistant	Default voice assistant (smartphone feature)	
4 I	Play previous track*	
▶ II	Play/pause*	
I	Skip to next track*	
ANC	Active Noise Cancelling	
OpenMic	Hear surroundings	
4	Mute	
-><-	Headphone LEDs	
\ / ឃុំ i	Call button/Press to interact with Microsoft Teams (app required)	
ψ	Power	
*	Bluetooth® pairing	

NOTE *Functionality varies by application. May not function with web-based apps.

Be safe

Please read the safety guide for important safety, charging, battery and regulatory information before using your new headset.



USB Bluetooth adapter



Your high-fidelity Bluetooth USB adapter comes pre-paired to your Poly device. Plug it into your computer to connect to high-fidelity computer audio.

NOTE Adapter's USB connection and design may vary, but function is the same.

Standard LEDs		
USB LEDs	What they mean	
Flashing red and blue	Pairing	
Solid blue	Headset connected	
Flashing blue	On a call	
Solid red	Mute active	
Flashing purple	Streaming media from computer	

LEDs when Microsoft Teams* is detected		
USB LEDs	What they mean	
Flashing red and blue	Pairing	
Solid purple	Microsoft Teams connected	
Flashing blue	On a call	
Solid red	Mute active	
Pulsing purple	Microsoft Teams notification	

NOTE *Requires Microsoft Teams desktop application.




Connect and pair

Connect to PC

Your Bluetooth USB adapter comes pre-paired to your headset.

1 Turn on your headset and insert the Bluetooth USB adapter into your laptop or PC.



- 2 The USB adapter LED flashes and then turns solid to indicate the headset is connected to the USB adapter. If you are wearing your headset you hear "PC connected" to indicate the connection has been established. When on a call, the LED on the USB adapter flashes blue. When not on a call the LED is solid.
- 3 Load Poly Lens Desktop App by visiting poly.com/lens. This allows you to customize your headset behavior through advanced settings and options.

Configure USB adapter

Your high-fidelity Bluetooth USB adapter comes ready to take calls. If you want to listen to music, you will need to configure your Bluetooth USB adapter.

Windows

- 1 To configure your Bluetooth USB adapter to play music, go to Start menu > Control Panel > Sound > Playback tab. Select Poly BT700 or Plantronics BT600, set it as the Default Device and click OK.
- 2 To pause music when you place or receive calls, go to Start menu > Control Panel > Sound > Communications tab and select the desired parameter.

Mad

1 To configure the Bluetooth USB adapter, go to Apple menu > System Preferences > Sound. On both the Input and Output tabs, select **Poly BT700** or **Plantronics BT600**.

Pair to mobile device

1 To put your headset in pair mode, slide and hold the Power \circlearrowleft switch away from the off position until you hear "pairing" and the headset LEDs flash red and blue.



- 2 Activate Bluetooth on your phone and set it to search for new devices.
 - iPhone Settings > Bluetooth > On*
 - Android Settings > Bluetooth: On > Scan for devices*

NOTE *Menus may vary by device.



3 Select "Poly V8200 Series."

Once successfully paired, you hear "pairing successful" and the headset LEDs stop flashing. **NOTE** Your headset can pair with up to 8 devices but only maintain 2 connections simultaneously; this includes the Bluetooth USB adapter.

Pair mode

Slide and hold the power button towards the Bluetooth icon until the LEDs flash red and blue.

Pair USB adapter again

Typically, your USB adapter is pre-paired to your Poly audio device. In the event that your adapter is disconnected or bought separately, you will need to pair the adapter to your Poly device. The adapter pairing method depends on which USB adapter you use.

Pair BT700 USB adapter again

Your USB adapter requires Poly Lens Desktop App to pair to a Poly audio device. Download: poly.com/lens.






BT700 USB-C

BT700 USB-A

- 1 Insert the high-fidelity Bluetooth USB adapter into your laptop or computer and wait for your computer to recognize it.
- 2 Put your Poly audio device in pair mode.
- 3 Launch Poly Lens Desktop App and navigate to Poly BT700.
- 4 Put your Bluetooth USB adapter into pair mode by selecting "Pair new device" on the adapter's main page or overflow menu. Your adapter flashes red and blue. Pairing is successful when you hear "pairing successful" and "PC connected" and the Bluetooth USB adapter LED is solid.


NOTE To pair again using Plantronics Hub Desktop App, navigate to the app's Poly BT700 general settings and select "Pair."

Pair BT600 USB adapter again



- 1 Insert the high-fidelity Bluetooth USB adapter into your laptop or computer and wait for your computer to recognize it.
- 2 Put your Poly audio device in pair mode.
- 3 Put your Bluetooth USB adapter into pair mode by pressing and holding the recessed pair button with a pen or paperclip until the Bluetooth USB adapter flashes red and blue.






NOTE Adapter design varies by USB connection.

Pairing is successful when you hear "pairing successful" and "PC connected" and the Bluetooth USB adapter LED is solid.

NFC pairing

- 1 Ensure NFC is on and your phone's display is unlocked.
- 2 Tap and hold the headphones to the phone's NFC tag location until NFC pairing completes. If necessary, accept the connection.

TIP Keep an eye on your Smartphone's screen for prompts to start and accept the pairing process.



NOTE The headphone's NFC tag is located on the outside of the left ear cup. Phone NFC tag locations vary.



Fit

IMPORTANT Headset microphones are on the front of your earcups.

For best call audio, ensure that left and right earcups are on the correct ear.



Load software

Customize your device behavior through advanced settings and options with Poly Lens App. Some softphones require the installation of Poly software to enable device call control (answer/end and mute) functionality. Download: poly.com/lens.

NOTE Device settings and updates are also available in Plantronics Hub App.

Update your Poly device

Keep your firmware and software up-to-date to improve performance and add new features to your Poly device.


Update your device using your computer with Poly Lens Desktop App. Download at poly.com/lens.

While updating:

- Do not use your Poly device until the update is complete.
- Do not start a second update from a second device.
- Do not stream media.
- Do not answer or place a call.



The Basics



Power on/off

Slide the switch \cup to power on or off.

Volume

Rotate the volume wheel ● ⁺ forward (+) or backward (-) to control the volume.



Adjust headset microphone volume (softphone)

Place a test softphone call and adjust softphone volume and PC sound volume accordingly.

Make/Take/End Calls

Answer a call

Choose:

- Tap the Call \ button
- Put on the headset to answer call

IMPORTANT For best call audio, ensure that left and right earcups are on the correct ear.

Answer a second call

First, tap the Call button \ to end current call, then tap the Call button \ again to answer new call.

End a call

Tap the Call button \ to end current call.

Mute/unmute

While on an active call, choose:



- Tap the red Mute button
- Take off/put on your headset while on an active call (requires active smart sensors)

Hold a call

Double-tap the Call $\$ button to put a call on hold. Tap the Call $\$ button again to answer an incoming call.

NOTE Up to 2 calls can be put on hold.

Switch between calls (flash)

Double-tap the Call \ button to switch between calls.

NOTE Flash functionality works only between calls of the same type. Flash does not work between mobile and softphone calls.

Call back last call

Double-tap the Call button \.

Answer calls from a second device

It's easy to answer calls from two devices (including softphone).

When on a call, you hear a ringtone notification of the incoming call from the second paired device.

To answer a second call from the other device, first tap the Call \ button to end the current call and tap the Call button again to answer the new call. If you choose to not answer the second call, it will go to voicemail.

Interact with Microsoft softphone

- For Microsoft Teams, tap the headset's Call \ button to interact (application required).
- For Skype for Business, press and hold the headset's Call \ button for 2 seconds to interact (application required).
- Set your target phone by going to Poly Lens Desktop App > Softphones > Software Settings > Target Softphone

Play/pause music

Tap the Play/pause ▶ II button.

NOTE Because your headset is equipped with sensors, if you are playing music and you take off your headset, your music pauses. If you put on your headset, your music resumes (functionality varies by application and doesn't function with web-based apps).

Track selection


Tap the Forward button ▶ or Back button ◀ to control the track selection.

Voice control

Siri, Google Assistant[™], Cortana Press and hold the Play/pause ▶ II button for 2 seconds until you hear the tone to activate your smartphone's default voice assistant.

Charge

It takes up to 3 hours to fully charge your headphones. The LEDs turn off once charging is complete.



TIP To check the headphones battery status, tap the Call \ button while wearing your headphones. Headphones must be in idle state.



Your headphones have up to 24 hours of listening time.



More Features

Use sensors

Smart sensors respond when you put on or take off your headphones. Customize in Plantronics Hub. Below describes default settings.

With active sensors	putting on the headphones will:	taking off the headphones will:
Mobile/softphone call	answer the incoming call	mute the active call
Music/media	resume music/media (if playing previous to taking off)*	pause music/media (if playing)*

NOTE *Functionality varies by application. May not function with web-based apps.

Reset Sensors

You may need to reset the sensors if they are not working as expected.

To reset the headset sensors, connect it directly to your computer's USB port, and place it, with the ear cups up, on a flat, non-metallic surface for more than 10 seconds.

ANC

Active Noise Cancelling (ANC) reduces external noise and enhances your music and sound quality.

Slide the ANC switch to choose:

- Mid: recommended for office
- High: recommended for airplane

OpenMic

When not on a call, tap the red # button to hear your surroundings (your music/audio will pause).



Troubleshooting

During a call, my voice sounds muffled or You may be wearing your headset backwards. far away to other callers. Headset microphones are on the front of your earcups. For best call audio, ensure that left and right earcups are on the correct ear. When I use my headset with a softphone, Check the following: the headset call control and mute • If required to enable headset control (answer/end buttons don't work. and mute) functionality, ensure you have Poly Lens Desktop App or Plantronics Hub for Windows/Mac installed. See Load software. • Mac only: if you are running Skype for Business softphone, quit Plantronics Hub for optimum headset call control. How do I interact with Microsoft Teams • For Microsoft Teams, tap the Call \ button to or Skype for Business? interact. For Skype for Business, press and hold the Call \ button for 2 seconds to interact. • Set your target phone by going to Poly Lens Desktop App > Softphones > Software Settings > Target Softphone Does my Microsoft Teams-enabled Yes, while your headset is optimized for Microsoft headset work with other softphones? Teams, it can be configured to use with other supported softphones. Set your target phone by going to Poly Lens Desktop App > Softphones > Software Settings > Target Softphone When you configure another softphone, the Call doesn't interact with Teams • doesn't go to Teams notifications will not launch Cortana The headset sound is not working as To configure the headset sound on your computer, expected when connected to computer. see Configure for media. During a call, nobody can hear me • During a call, I can't hear anybody • Music is not coming through my headset • When I play music and a call comes in, the music is too loud or doesn't pause Install Poly Lens Desktop App. I can't unmute my headset when I'm on a softphone call. The headset sensors are not working as If your headset sensors are not working as expected, you may need to reset the sensors. See Reset sensors. expected. A call is not automatically answered when I put on my headset • Mute/unmute is not working when I take



on/off my headset during a call

• During a call, mute unexpectedly turns on

During a call, I get interference and drop in sound.	Your headset is configured for optimal performance during conference calls. Stereo telephony is on by default. To increase Bluetooth density, change the setting by going to Poly Lens Desktop App>Settings > Wireless > Extended Range Mode.	
The headset talk time is not accurate.	Charge the headset fully to reset the accuracy of the talk time prompts.	
I hear an echo when not on a call.	Check and see if OpenMic is on by pressing the red mute button when you are not on a call. Our exclusive OpenMic feature lets you control the level of ambient noise you hear.	
On my Mac, I can't change headset	Skype for Business and Lync users only:	
settings with Plantronics Hub	1 Quit Skype for Business or Lync softphone.	
	2 Open Plantronics Hub for Mac and configure desired settings.	
	3 Quit Plantronics Hub.	
On my Mac, I can't update headset firmware with Plantronics Hub	Skype for Business and Lync users only: 1 Quit Skype for Business or Lync softphone.	
	Open Plantronics Hub for Mac and update headset firmware. See Update firmware.	
	3 Quit Plantronics Hub.	
On my Mac, if I'm listening to streaming audio and take off the headset, iTunes starts playing when I put the headset back on.	This is a known issue. Turn off play/pause setting in the sensors tab of Poly Lens App or Plantronics Hub for Windows/Mac.	



Support

NEED MORE HELP?

poly.com/support

Plantronics, Inc. Plantronics B.V. 345 Encinal Street Scorpius 171

Santa Cruz, CA 95060 2132 LR Hoofddorp

United States Netherlands

210802-0607.21



^{© 2021} Plantronics, Inc. All rights reserved. Poly, the propeller design, and the Poly logo are trademarks of Plantronics, Inc. Bluetooth is a registered trademark of Bluetooth SIG, Inc. and any use by Plantronics, Inc. is under license. All other trademarks are the property of their respective owners. Manufactured by Plantronics, Inc.