



## Does the SD card slot on the ADC-V515 have any functionality?

Yes. An SD card can be inserted into the ADC-V515 so that it can record continuously without additional hardware. For more information, see [Local SD card recording for video devices](#).

**Note:** The SD card recordings contain video only.

### To install an SD card in an ADC-V515:



1. Verify the device is upgraded to the latest firmware available.
2. Locate the SD card slot on the bottom side of the camera near the QR code and MAC address.
3. Orient the micro SD card with the metal pins facing towards the front of the camera.
4. Insert the SD card into the slot until it clicks.

### To enable onboard recording:

1. Verify that the micro SD card is inserted into the camera.
2. Log into the Customer Website.
3. Click **Video**.



4. Click **Recording Rules**.
5. Click **Local Recordings**.
6. Click **+ Add New Schedule**.
7. Using the *Select a camera to record from* dropdown menu, select the desired device.
8. Using the *Select recording quality* slider, select the desired quality.
9. In *Schedule recording time*, click to select either **At all times** or **Only during the following times**.
  - If **Only during the follow times** is selected:
    - a. Click to select the desired days to record.
    - b. Using the *Starting at* and *Ending at* dropdown menus, select the period to record in hours.
10. To limit the number of days that recordings are kept:
  - a. Click the *Limit the number of days to record* toggle switch to enable a limit.
  - b. Using the dropdown menu, select the desired number of days to limit the recordings to.
11. Click **Save**.

